TELOS PROSTREAM

Encoder for Streaming Audio

USER'S MANUAL

ProSTREAM manual v2, for ProSTREAM software v2.1
Applies to: 2001-00254

Description:

Telos ProStream combines audio processing with MP3 and AAC encoding in one convenient single-rack unit. The AAC encoder supports AAC-LC, HE-AAC and HE-AAC v2 formats. Can be fully managed and configured remotely with a web browser. Features a wideband AGC, 3-band compressor/limiter, EQ, low-pass filter and a precision look-ahead final limiter. Encodes the processed audio directly to MP3 or AAC streams and feeds a remote replication server at the ISP. Streams can be "tagged" with "now-playing" information received from automation systems. Rackmount, 1RU.

1 *Quick Start* *1*

Settings 1

Audio 1

Network 2

Omnia Processing 2

Codec 1 & 2 3

MP3 3

AAC. 3

Low Complexity 3

High Efficiency V2 3

Stream Configuration 4

SHOUTcast DNAS v2.0 Example 4

SHOUTcast configuration file 4

Stream 1. 5

Stream 2. 6

ICEcast Example 7

ICEcast Config file 7

Stream 3. 7

Stream 4. 8

2 *Introducing ProSTREAM* *11*

3 *Controls and Connections* *13*

Overview. 13

Front Panel 13

Back Panel 14

Status Display 14

IN/OUT 15

Automatic Gain Control [AGC] 15

Limit 15

Editing Text. 16

text entry mode 16

erase mode 16

Web Configuration 17
Default Credentials 17

4 *ProSTREAM Configuration* *19*
Audio Menu 19
Audio I/O interface 19
XLR (analog). 19
Input audio gain 19
Output audio gain 19
Livewire. 20
Input Livewire channel (destination):. 20
Output Livewire channel (source): 20
Network Menu 21
LAN Interface 22
Mode 22
(Auto) DHCP 22
MANUAL. 22
DISABLED 22
IP Address. 22
(Auto) DHCP 22
MANUAL. 22
Netmask 22
(Auto) DHCP 22
MANUAL. 22
Gateway 22
(Auto) DHCP 22
MANUAL. 22
WAN Interface 23
Mode 23
(Auto) DHCP 23
MANUAL. 23
DISABLED 23

IP Address . . . 23
(Auto) DHCP . . . 23
MANUAL . . . 23
Netmask . . . 23
(Auto) DHCP . . . 23
MANUAL . . . 23
Gateway . . . 23
(Auto) DHCP . . . 23
MANUAL . . . 23
DNS Servers . . . 23
Codec [1 & 2] . . . 24
Compression Codec . . . 25
MP3 "The standard for digital audio" . . . 25
AAC-LC "Low Complexity" . . . 25
HE-AAC "High Efficiency" . . . 25
Channels . . . 25
Bitrate . . . 26
Transport (AAC only) . . . 26
ADTS . . . 26
ADTS-CRC . . . 26
ADIF . . . 26
RAW . . . 26
Metadata . . . 27
Input . . . 28
Process . . . 29
Custom Metadata Scripts . . . 31
Lua Script Example . . . 31
Code Breakdown . . . 31
Metadata Tools . . . 32
Metadata Pack . . . 32
MetadataCapture.exe . . . 33
MetadataSend.exe . . . 33
Syslog Server . . . 35
File to TCP . . . 36

Command Line usage 36
Streams 37
HTTP Streaming 37
Streaming Services 38
Stream Server Service Providers 38
SHOUTcast 38
Target Server 39
SHOUTcast Server Address 39
SHOUTcast Server Password 39
Stream Name 39
Stream Genre 39
Stream URL 39
Server version 39
Stream ID 39
Stream availability 39
ICEcast 40
Target Server 40
Audio Codec 40
ICEcast Server Address 40
Mount Point 40
Stream User Name 41
Stream Password 41
Metadata User Name 41
Metadata Password 41
Stream Name 41
Stream Genre 41
Stream URL 41
Stream availability 41
RTP 41
Target Server 42
Audio Codec 42
RTP destination address 42
RTP destination port 42
Time to live (TTL) 42

Stream name. 42
RTP interface 42
RTMP 43
Target server 43
Server address 43
Use Authentication 43
Stream user name 44
Stream password 44
Publish path 44
Stream name. 44
System. 44
Advanced Options. 45
Logs 45
Ping Service 46
Host IP 46
Ping Interval. 46
Alarm after 47
Configure Static Routes 47
Destination Address 47
Gateway Address. 47
Interface 47
View network diagnostics 48
Interface configuration 48
Link information 48
IP rules 48
IP routing 49
View memory usage diagnostics 50
View system diagnostics 51
View front panel image 52
Display public IP (works only if DNS is configured) 52

5 *Omnia Processing* *53*

Preset Editor 54

Processor Adjustment Overview 54

Processor Adjustment 55

Bypass. 55

Input 55

Gain. 55

WB AGC 55

Drive. 56

Gate 56

Release 56

Bass. 56

Phat Bass. 57

Deep Bass 57

X-Over. 57

Low,Mid,Hi AGC 57

Drive. 58

Gate 58

Release 58

Mix 58

Level [Low, Middle, High] 58

Final Limiter 59

Limiter. 59

Output 60

Gain [Left & Right] 60

Output Filter 60

Managing Presets 61

6 *Warranty and Application Cautions* *63*

7 *Specifications* *65*

8 *Safety Notification* *67*

1 Quick Start

Streaming with ProSTREAM involves the following primary tasks:

1. select the audio input,
2. configure the network settings,
3. select an audio processing preset,
4. select the codec used to encode the stream, and
5. select a destination server to distribute the stream to the end-listeners.



This section walks you through a simple setup where the ProSTREAM is fed analog audio, the network settings are configured via DHCP, and the stream is sent to a ShoutCAST v2 server. If your setup is different, you may safely skip this section. If this is the first time you have used a ProSTREAM, you may to have a look at the [Front Panel] and [Entering Text] sections before you proceed.

Settings

From the front panel of the ProSTREAM, set the following menu options.

Audio



- Connect an audio source to the XLR inputs and select Audio Input: XLR.

- Verify Input Gain Setting is **0.0 db**.

Audio signal should now be visible on the input metering.

Increase INPUT gain by pressing the encoder knob, turning, and then pressing again to set the value.

Network

The ProSTREAM offers WAN and LAN/Livewire network ports. In most configurations you only need to connect the WAN port to the network and the LAN port is set as "disabled". When using Livewire, the LAN port is connected to the Livewire network and the WAN port is connected to the public/outside network.

NOTE:

Do not connect both ports to the same network!
Unless you are using the LAN port with Livewire Audio over IP, configure it as "disabled".

Connect the WAN Ethernet port to the network. Under Network -> WAN Mode, set the WAN port to Auto（DHCP）.

After a reboot, the Network -> WAN IP Address should now show a valid IP address for the connected network.

Omnia Processing

In the Omnia Processing dialog, select a processing preset best suited to the audio source material. If unsure, use **Normalize**. If no audio processing is desired, select the processing preset as [**none**].

Only processing preset selection is available on the front panel interface. Preset adjustment can be done via ProSTREAM's internal web configuration by means of a web browser.

Note:

All ProSTREAM local outputs (XLR, Livewire, and headphone output) are post-process and pre-encode. The post-process audio can be monitored via the output metering of the Status display.

Processing adjustments will be heard real-time on local outputs, but will be heard with a certain amount of delay in the encoded stream. A small portion of this delay is introduced by the encoder while a much larger portion is introduced by buffering in the server and the client used to listen to the stream.

Note: Switch headphone monitoring between pre-processed audio and post-processed audio by pressing the headphone volume knob and selecting "Listen to [**input**|**output**] audio."

Codec 1 & 2

Choices are MP3, AAC, or None. Common output settings are as follows:

MP3

- Sample Rate: **44100 Hz**
- MP3 Channels: **Stereo**
- MP3 Bitrate（16-320 kbps）: **128**

AAC

Low Complexity

（Good for 3G networks）

- AAC Format: **AAC-LC**
- AAC Channels: **Stereo**
- AAC Bitrate（24-320 kbps）: **96**
- AAC Transport: **ADTS**

High Efficiency V2

（Good for Edge/2G networks and lower bit-rates）

Sample Rate: **44100 Hz**

- AAC Format: **HE-AAC v2**
- AAC Channels: **Stereo**
- AAC Bitrate（14-56 kbps）: **48**
- AAC Transport: **ADTS**

Once the Codec encoders are configured, it should be possible to monitor the encoded audio streams via a connected network audio player. Each codec can be monitored separately via the ProSTREAM's internal Stream Server. In the table below, "ip.address" represents the IP address assigned to the ProSTREAM.

Test Stream Connection URL's

Codec 1	Codec 2
PLS: http://ip.address/play.pls	PLS: http://ip.address/play2.pls
M3U: http://ip.address/play.m3u	M3U: http://ip.address/play2.m3u
ASX: http://ip.address/play.asx	ASX: http://ip.address/play2.asx
RAW: http://ip.address:8000	RAW: http://ip.address:8010

Note:

The ProSTREAM's playlist links are for testing only and should NEVER be deployed as public connection points. Always use a streaming server.

Stream Configuration

Stream configurations are provided by the stream relay provider or set in the stream server configuration files. ProSTREAM has four (4) configurable stream uplinks which can be set to push audio from either of the two (2) available encoded codecs.

SHOUTcast DNAS v2.0 Example

The free SHOUTcast DNAS software is a good example of a streaming server. SHOUTcast DNAS is avalable at http://www.shoutcast.com/broadcast-tools. A single SHOUTcast instance is capable of relaying both ProSTREAM codecs, and will require the configuration of 2 of the available 4 stream configurations.

SHOUTcast configuration file

SHOUTcast operates by means of specifying a configuration file at launch, typically, **sc_serv.conf.** The following parameters are needed from the SHOUTcast configuration file.

```
portbase=8010

password=streampwd

adminpassword=adminpwd
```

At least two stream ID's should be specified.

```
streamid_1=1

streamid_2=2
```

Stream 1



- Stream Type: SHOUTcast
- Codec: Codec 1
- Server Address: *SHOUTcast.ip:{portbase}* [example: **192.168.2.200:8010**]
- Server Password: *{password}* [example: **streampwd**]
- Stream Name: *Name of Stream* [sent to clients]
- Stream Genre: *Genre of Stream* [SHOUTcast guidelines]
- Stream URL: URL of Station Website [sent to clients, example: http://TelosAlliance.com]
- Server version: **version 2**
- Stream ID: **1**
- Stream Availability: **public**


http://192.168.2.200:8010/index.html?sid=1
SHOUTcast Administrator
SHOUTcast DNAS Status
SHOUTcast Server v2.0.0.29/posix(linux x86)
Status | Song History | Listen | Stream URL | Admin Login
Current Stream Information
Server Status: Server is currently up and public (no YP connection)
Stream Status: Stream is up at 96 kbps with 0 of 128 listeners (0 unique)
Listener Peak: 0
Stream Name: Name of Stream
Content Type: audio/aac
Stream Genre: livewire
Stream URL: http://TelosAlliance.com

The **Listen** link now provides a stream listen URL for client deployment.

Stream 2



- Stream Type: SHOUTcast
- Codec: Codec 2
- Server Address: *SHOUTcast.ip:{*portbase*}* [example: **192.168.2.200:8010**]
- Server Password: {password*}* [example: **streampwd**]
- Stream Name: *Name of Stream* [sent to clients]
- Stream Genre: *Genre of Stream* [SHOUTcast guidelines]
- Stream URL: URL of Station Website [sent to clients, example: http://TelosAlliance.com]
- Server version: **version 2**
- Stream ID: **2**
- Stream Availability: **public**



Two streams are now avalable from the SHOUTcast DNAS server.

ICEcast Example

Icecast is a free stream relay software available from http://www.icecast.org/.

ICEcast Config file

ICEcast must be launched with a configuration file specification, typically, **icecast.xml**. The following parameters are required from the ICEcast configuration file.

```
<authentication>
   <source-password>streampwd</source-password>
   <relay-password>relaypwd</relay-password>
   <admin-user>admin</admin-user>
   <admin-password>adminpwd</admin-password>
</authentication>
<listen-socket>
   <port>8000</port>
</listen-socket>
```

ICEcast per-stream configuration is un-needed. Streams are distinguished by the mount point configuration which is specified in the source device [ProSTREAM].

Stream 3

- Stream Type: ICEcast
- Codec: Codec 1
- Server Address: *ICEcast.ip:{port}* [example: **192.168.2.200:8000**]
- Mount Point: **hifi** [can be any URL compatible string]
- Server Username: **source** [can be overridden in icecast.xml config]
- Server Password: `<source-password>` [example: **streampwd**]
- Metadata Username: `<admin-user>` [example: **admin**]
- Metadata Password: `<admin-password>` [example: **adminpwd**]
- Stream Name: ***ProSTREAM HiFi*** [sent to clients]
- Stream Genre: ***livewire***
- Stream URL: URL of Station Website [sent to clients, example: http://TelosAlliance.com]
- Server version: **version 2**
- Stream Availability: **public**

Stream 4



- Stream Type: ICEcast
- Codec: Codec 2
- Server Address: *ICEcast.ip:{port}* [example: **192.168.2.200:8000**]
- Mount Point: **lofi** [can be any URL compatible string]
- Server Username: **source** [can be overridden in icecast.xml config]
- Server Password: `<source-password>` [example: **streampwd**]
- Metadata Username: `<admin-user>` [example: **admin**]
- Metadata Password: `<admin-password>` [example: **adminpwd**]
- Stream Name: ***ProSTREAM LoFi*** [sent to clients]
- Stream Genre: ***livewire***
- Stream URL: URL of Station Website [sent to clients, example: http://TelosAlliance.com]
- Server version: **version 2**
- Stream Availability: **public**


http://192.168.2.200:8000/
Icecast Streaming Medi...
Icecast2 Status
Administration
Server Status
Version
Mount Point /hifi
M3U
XSPF
Stream Title: ProSTREAM HiFi
Stream Description: ProSTREAM HiFi
Content Type: audio/aacp
Mount started: Sat, 04 May 2013 20:08:43 -0500
Bitrate: 96
Current Listeners: 0
Peak Listeners: 0
Stream Genre: livewire
Stream URL: http://TelosAlliance.com
Current Song:
Mount Point /lofi
M3U
XSPF
Stream Title: ProSTREAM LoFi
Stream Description: ProSTREAM LoFi
Content Type: audio/aacp
Mount started: Sat, 04 May 2013 20:08:48 -0500
Bitrate: 48
Current Listeners: 0
Peak Listeners: 0
Stream Genre: livewire
Stream URL: http://TelosAlliance.com
Current Song:

2 Introducing ProSTREAM

The Telos Systems ProSTREAM is a hardware-based audio processor and web stream encoder device in a compact 1U rack-mount chassis. The ProSTREAM will process and encode audio sourced from either rear-mounted analog audio inputs or via Livewire audio over IP technology[1].

ProSTREAM uses Omnia Audio's proven audio processing algorithms[2] to balance the input audio according to the program's format. The processed audio is then encoded by two distinct encoders. ProSTREAM can send the encoded streams to up to four streaming servers or streaming service providers. The processed audio is also sent to XLR and Livewire outputs for monitoring.

The ProSTREAM can also accept and parse incoming metadata. The metadata is then sent along with the stream to the streaming server, which will then distribute it to end listeners. It is important to note that listeners always connect to the streaming server, never directly to ProSTREAM.

FYI: MPEG License & Music Copyright

Musical compositions and sound recordings are creative works that are protected by the copyright laws of the United States (title 17, U.S. Code) and other countries. Under U.S. law, the owner of a copyright has the exclusive right (and may authorize others) to reproduce the work, use parts of the work in a new creation, distribute the work in whole or in part, and to publicly display or perform the work (including on web pages and through webcasting). With few exceptions, it is illegal to reproduce, distribute or broadcast a sound recording without the permission of the copyright owner. It is your responsibility to comply with the copyright laws of the United States and other countries in which you broadcast and to pay all applicable royalties to the copyright owners when you become a webcaster.

There have been recent amendments to the copyright law regarding webcasting of sound recordings. These new provisions allow webcasting under the terms of a statutory license, as a way to help webcasters get permission without having to go to each sound recording's owner. The statutory license, however, has strict requirements that you must follow. Some of these requirements include the payment of license fees, limitations on the number of songs from the same album or artist that may be played in a three hour period (called the sound recording performance complement); a prohibition on publishing advance playlists; and a requirement to identify the song, artist and album on the website. There are other requirements as well. The Recording Industry Association of America provides quite a bit of information on copyright law as it applies to webcasting, and both ASCAP and BMI have created license agreements that they are willing to grant to webcasters that they believe conform to the provisions of the new copyright rules for webcasting.

For additional information on the statutory license and other aspects of webcasting, please visit the following sites:

The U.S. Copyright Office http://www.copyright.gov

The Recording Industry Association of America http://www.riaa.com/issues/music/webcasting

ASCAP http://www.ascap.com/weblicense/webintro.html

BMI http://www.bmi.com/iama/webcaster/index.asp Streaming Server software

---

1 For more information on Livewire, please visit http://axiaaudio.com/livewire.

2 For more information regarding Omnia processors, please visit http://omniaaudio.com.

3 Controls and Connections

Overview

The Telos ProSTREAM is very simple to set up and use, having a minimal amount of controls and an easy, intuitive interface. Here, we'll take a look at the front and rear panels of your ProSTREAM.

The packing box contains:

- Telos Systems ProSTREAM unit
- AC power cords (Euro 220v, US 110v, unterminated)
- RJ45 network cable
- #10 rack screws
- warranty registration form
- warranty information sheet

Front Panel

1. **Power LED**: The blue power LED is located to the upper left of the display. When the unit is first powered, the power LED will flash until the unit is fully booted. When booted, the power LED will light solid.
2. **Display Screen**: The OLED display screen displays audio meters and configuration information. Use the display, control knob, and return button to navigate the ProSTREAM's options and settings.
3. **Control Knob**: The main control knob, next to the display, works as a selector. Rotate the knob until the desired option is displayed, then press the control knob to select the option. The control knob is also used in similar fashion for character selection in text entry fields.
4. **Back Button**: The back (or escape) button is adjacent to the control knob. Pressing it steps back, or exits, from a selected option or dialog. Pressing it repeatedly, will return you to the main screen (and will also toggle between the main and status screens).
5. **Headphone Jack**: 1/4" Stereo TRS Jack for monitoring the input and post-process output audio.
6. **Headphone Volume Knob**: The headphone volume knob controls the output level of the audio being sent to the headphone jack. Pressing the headphone volume knob will toggle the headphone output between monitoring the input audio and the post-process output audio.

Back Panel

1. **AC Mains connection**: 110 - 220v auto-switching power connection. Use supplied power cord appropriate for your area.
2. **LAN Network**: The LAN network jack is a 10/100 RJ45 jack and can be used with a Livewire network for source audio and post-process audio monitoring.
3. **WAN Network:** The WAN network jack is a 10/100 RJ45 jack typically used to send the encoded streams to streaming servers.

   NOTE:

   ProSTREAM provides two network interfaces for configuration flexibility. If you are not using Livewire, then you only need to configure one interface. Make sure to leave the other interface as "disabled." Do not connect both interfaces to the same network!

4. **Analog Audio Inputs**: (female 3-pin XLR, left & right)
5. **Analog Audio Outputs**: (male 3-pin XLR, left & right)
6. **USB**: RS232 metadata input (with optional USB-to-Serial Adapter P/N 2091-00140)
7. **Parallel Interface**: no current functions

Status Display



The Status screen shows the audio processing meters and indicators. ProSTREAM's audio processor is capable of performing many different processing functions at different times, primarily based on dynamic range differences in the source audio.

The meters analyze the signals and aid in adjusting the specific parameters needed to achieve desired aural results. Although the processing displays are capable of providing a wide range of information, we recommended setting the audio processing based on how it sounds best to you, not relying entirely on meter indications.

IN/OUT

The Status bar graphs are capable of indicating more than just level information. The texture and density of the audio signal can be observed, based upon the dynamic action of the bar graphs, and peak-responding pills.

Of interest are the pills at the end of the input and output meters which indicate peak level. The bar section represents the RMS average of the signal. Wide dynamic range will display a separation between the pills and the bar, whereas signal with little peak information will cause the pills to ride on the crest of the bar graph. The bar graphs can indicate up to 25 dB of gain reduction.

Note:

The input and output levels are displayed relative to 0dB full scale (0dBfs). The 0 indicator on the input/output bar graphs means that every available bit of signal level is being used at that time and that there is nothing more in the level department, except to create distortion.

Automatic Gain Control (AGC)

There are two sections to the AGC bar graphs display: wide-band automatic gain control（WB-AGC）and multiband automatic gain controls. The multiband AGC bands are low frequency, mid frequency, and high frequency. The bar shows the average value of the gain reduction, while the floating pill indicates the peak value of gain reduction.

The Omnia processor algorithms automatically adapt the style of compression/limiting control being employed on a moment-by-moment basis. This can be deduced if the metering is studied over time. During normal operation, the bar graphs will have a dynamic "bounce." Every now and then, the processor will react quickly and show a larger amount of gain reduction. This action will recover very slowly, and return to rest with the main bar graph. This action is more apparent on dynamically textured audio.

Another feature unique to Omnia processing is processor hold. During brief pauses in audio, the bar graphs will "freeze" indicating the processor is in the hold mode of the algorithm. This can occur when there is dry vocal audio in the signal.

Bar graphs will indicate differently for pre-processed audio than with widely-varying audio level content. Audio signals which lack dynamic range, whether naturally or by prior processing, will possess a lower peak to average ratio. Conversely, audio with wide dynamic range possesses a higher peak to average ratio. ProSTREAM adapts to each case.

Low dynamic range audio（audio with high RMS and low peak levels）will show more activity in the WB-AGC bar graph and less activity in the multiband bar graphs. The WB-AGC responds to high RMS energy while the multiband section reacts to lower peak energy. Multiband bar graphs may not indicate any action at all with some low dynamic range audio which is normal for Omnia processing. This may occur with heavily processed commercials or music, or with music passages of sustained level.

Wide dynamic range audio（audio with low RMS and high peak levels）causes the opposite to occur. The multiband bar graphs become active, while the WB-AGC section appears to not respond as much. The multiband AGC's can work aggressively with wide dynamic range audio while the WB-AGC section indicates little activity.

The WB-AGC section is designed to operate much slower than the multiband gain controls, primarily because of the nature of each function. The WB-AGC operates on the audio's RMS energy. During gain calculations, the incoming audio's "average" level is established, and gain adjustments, if needed, are made based on those calculations. The WB-AGC bar graph will appear to move slower as it makes changes over relatively long time periods.

The intent of the multiband gain control is to normalize the spectral balance and provide control of the peak levels. Peak energy must be detected and adjusted in a quick and accurate manner but not interfere with the sonic integrity of the audio signal. For this reason, the multiband gain controls operate faster, with special background instructions to govern their behavior, and strictly on an as-needed basis.

Limit

The limit bar graphs monitor the level to which the processor is engaging gain reduction in the post-process audio for each the left and right channels.

Entering and Editing Text in the Front Panel UI

Since the ProSTREAM's user interface consists of a selector knob and back button, the method for entering text or numeric information may not be immediately obvious. This section describes how text entry and editing is accomplished. The task seems complex at first, especially when described in words, but it is very simple once you have a chance to practice it a bit; similar to learning to tie one's shoe laces.

When a text field is displayed, the pencil icon indicates that the field is changeable. Press the main knob to enter one of the edit modes. The edit mode is indicated by the cursor shape: a solid cursor indicates text entry mode, while a rectangle outline cursor indicates erase mode.

text entry mode (solid cursor)

In text entry mode, turning the knob cycles through all available characters. Press the main knob to select the current character; the cursor will move to the next character position. While in text entry mode, pressing the Back button once switches the cursor to erase mode.

erase mode (hollow rectangle cursor)

In erase mode, turning the knob erases (or restores) characters. While in erase mode, press the main knob to return to text entry mode or press the Back button to exit field editing altogether.

Web Configuration

The ProSTREAM has an internal web server accessible via a web browser. The web interface can be reached by pointing a web browser to the IP address of either LAN or WAN network, for example **http://192.168.1.15/**.


Telos
ProSTREAM
Main
Help
Welcome to ProStream. Select from the options below to configure the system.
Audio
Network
Omnia Processing
Codec 1
Codec 2
Metadata
Stream 1
Stream 2
Stream 3
Stream 4
System
Advanced Options
You may also click one of the following links to listen to the encoded stream using your media player:
Codec 1: asx pls m3u
Codec 2: asx pls m3u
NOTE1: The login credentials can be viewed and changed via the front panel interface of your ProStream (in the System menu).
NOTE2: A Javascript-enabled browser is required. The Silverlight plug-in from Microsoft is required for viewing the audio meters and for preset editing. If you do not already have this plug-in installed, you will be prompted to do so the first time you access a page that uses it. For best compatibility, we recommend using the Internet Explorer browser.

Default Credentials

The default credentials to access the web interface are:

- username: **admin**
- password: **Telos**

NOTE:

For security reasons, it is very important to change the default login credentials. Failure to do so may give others access to your ProSTREAM. The login credentials can be changed on the front panel, under the System dialog.

NOTE:

The ProSTREAM web configuration requires Javascript and Microsoft Silverlight (for real-time Omnia processor adjustment). Some settings and values may be locked or unavailable if they depend on other configured options.

4 ProSTREAM Configuration

Audio Menu

Audio I/O interface

XLR (analog)



Input audio gain
[0.0 dB-22.5 dB] The Audio Input Level is adjustable from a 0dB level of gain to 22.5 dB level of gain. Gain level is not necessary as +4v balanced audio will show input status at a setting of 0db..

Output audio gain
[-95.2 dB - 0.0 dB] The Audio Output Level affects the signal level for the ProSTREAM's rear outputs and Livewire returns. The default setting of 0.0 dB will direct the full level of the processed audio to the ProSTREAM outputs.

Note:

The post-process audio to the encoder is unaffected by the Audio output Level setting internally.

Livewire


Audio I/O interface:
Livewire
Warning: Uncompressed audio generates a lot of network traffic. Do not use Livewire unless you have a properly configured network switch!
Input Livewire channel (destination):
10801
Output Livewire channel (source):
10901
Save

Livewire is an audio over IP technology from Axia Audio. Livewire audio requires that specific conditions be met in the network switching environment to use Livewire functionality. As a multicast IP protocol requiring both IGMP routing and QoS parameters, common consumer network routers and switches are unable to use Livewire IP technology. For more information, please visit http://axiaaudio.com/livewire.

Livewire connections should utilize the LAN port and typically imply a manual IP configuration.

Input Livewire channel (destination):
Enter the channel number of an active Livewire IP audio source channel generated by another Livewire device.

Output Livewire channel (source):
Enter a unique channel number to appear on the Livewire audio network（connected to the ProSTREAM LAN/ Livewire network jack）.

Network Menu



The ProSTREAM is equipped with two RJ45 gigabit network ports marked *LAN* [Local Area Network] and *WAN* [Wide Area Network]. The networking settings of the ProSTREAM are of IPv4 conventions and must be assigned an IP address before the ProSTREAM will communicate with any other devices.

LAN Interface

Mode

(Auto) DHCP
IP address is provided by a DHCP server on the network.

Note: Livewire network devices are typically configured with a Manual IP address, not DHCP.

MANUAL
A standard IPV4 IP address must be specified.

DISABLED
Disable the LAN port.

IP Address

(Auto) DHCP
The IP Address field will show current IP address, or 0.0.0.0 if no address is assigned.

MANUAL
A valid IPV4 IP address must be specified.

Netmask

(Auto) DHCP
The Nemask field will show the value assigned by the DHCP server.

MANUAL
A valid IPV4 netmask must be specified.

Gateway

(Auto) DHCP
The Gateway field will show the value assigned by the DHCP server.

MANUAL
Specifying a gateway is optional. If the WAN port is in use for connection to the Internet, set the LAN gateway to 0.0.0.0. If the WAN port is disabled, specify the IP address of the network gateway router.

WAN Interface

Mode

(Auto) DHCP
IP address is provided by a DHCP elsewhere on the network. This is the default configuration when connecting to a network routed by a typical consumer-brand gateway router device for Internet access.

MANUAL
A standard IPV4 IP address must be specified.

DISABLED
Disable the WAN port.

IP Address

(Auto) DHCP
The IP Address field will show current IP address, or 0.0.0.0 if no address is assigned.

MANUAL
A valid IPV4 IP address must be specified.

Netmask

(Auto) DHCP
The Nemask field will show the value assigned by the DHCP server.

MANUAL
A valid IPV4 netmask must be specified.

Gateway

(Auto) DHCP
The Gateway field will show the value assigned by the DHCP server.

MANUAL
Specifying a gateway is optional. If the WAN port is in use for connection to the Internet, specify the IP address of the network gateway router.

DNS Servers

DNS server entry is not required, but recommended. DNS is what allows a named address (google.com) to refer to a numerical address (74.125.255.134). If local DNS servers are unknown or unavailable, Google's public DNS server can be used with the IP addresses **8.8.8.8** & **8.8.4.4**.

Codec [1 & 2]



The codec represents the manner in which the 1.4Mbps stream of un-compressed audio data will be converted into a smaller data stream by means of digital compression. ProSTREAM applies lossy compression algorithms[1] to the processed audio in order to create a live data stream for end users via the Internet. A lossy compression technique produces a data stream small enough to be delivered to the client via DSL, EDGE wireless, or any common Internet network infrastructure.

MPEG has released different standards as technology has required, and each successive standard has built upon the previous yielding modern codecs which can deliver extremely clear audio at incomprehensibly high ratios of compression.

When selecting a codec, there is a trade-off between more modern compression standards which sound much better than older standards, but may risk incompatibility with older client software and devices. The core of this choice will likely be between .MP3（MPEG Audio Layer III）and the newer and aptly named Advanced Audio Coding（AAC）（MPEG-4 with MPEG-2 components）.

Many factors may be considered when choosing a codec to employ for the output stream.

- Is content mostly vocal or musical?
- How is the processor tuned?
- What types of clients are connecting to the audio stream?

---

1 Telos Systems licenses Motion Picture Experts Group [MPEG] compression codecs from Fraunhofer IIS [http://www.iis.fraunhofer.de/en/bf/amm/produkte/audiocodec/] and includes the codecs as a source component of ProSTREAM. Lossless encoding, like a ZIP or DMG file on a computer allow an end user to un-compress the data and restore all of the original information. In order to gain much greater compression ratios, audio compression employs lossy compression or encoding by making certain assumptions about human hearing. For instance, a C# note played by a guitar at 85 db of power overpowers a C harmonic of a keyboard at 30 db of power, so the 30db signal is minimized or tossed.

Lossy compression relies upon subjective process, thus there are many techniques to digitally compress audio and there are many more opinions as to which are best. In anticipation of the need for compression algorithms, the Motion Picture Experts Group (MPEG) [http://mpeg.chiariglione.org/] was formed by the International Standards Organization (ISO) [http://www.iso.org/] and the International Electromechanical Commission (IEC) [http://www.iec.ch/] to address the needs of digital compression. Their research has yielded the codecs licensed and used by ProSTREAM.

Compression Codec

It is generally accepted that AAC performs better and is the codec of choice. It is rare to find clients which are MP3 only a decade after the AAC codecs became standard, but they do still exist. MP3 was released in 1993 and as the first digital compression technique to find widespread acceptance is in most all digital stream clients that exist.

AAC benefited greatly from being the second go at audio compression as it was able to be designed with all that was learned with MP3. AAC also boasts multiple "profiles" to fit the need of the transmission.

MP3 "The standard for digital audio"

MP3 is an all encompassing audio compression codec. MP3 is the safest choice for decoding compatibility, but creates the least clear audio of all codecs available.

AAC-LC "Low Complexity"

Formerly known as aacPlus or AAC+, Advanced Audio Coding's Low Complexity codec is a high performance codec for excellent audio quality at standard bitrates. AAC-LC can be found in widespread use, most notably in Apple's iTunes. When compared side by side with MP3, the superior quality of audio encoded with AAC-LC becomes much more apparent at lower bitrates.

HE-AAC "High Efficiency"

High Efficiency Advanced Audio Coding is a newer AAC codec and incorporates Spectral Band Replication（SBR）bandwidth expansion to improve audio at very low bitrates.

HE-AAC v2 applies a Parametric Stereo feature to HE-AAC codec allowing for even further reduction in bandwidth.

Channels

Choose from mono or stereo encoding.

Bitrate

The full spectrum of ProSTREAM encoding can be anywhere from 14-320 kbps for the output data stream bitrate. The output bitrate constraints will differ depending on which codec is selected and whether the encode is set to mono or stereo. The range of each codec is shown in the table below:

Codec	Bitrate Range
MP3	16 to 320 kbps
AAC-LC	24 to 320 kbps
HE-AAC	24-96 kbps
HE-AAC v2	14-56 kbps

Transport (AAC only)

AAC audio encoding does not specify a container form for packaging the data stream. The Transport option allows you to select one of four available formats: ADTS, ADTS-CRC, ADIF, or RAW. If you're not sure about this setting, just keep the default value（ADTS）or select a transport format that is understood by the audio player you are targeting（some testing may be required）.

ADTS

The default transport container to use for all AAC codecs is Audio Data Transport Stream（ADTS）. ADTS encapsulates the packetized elementary streams of encoded AAC audio and metadata for transport over IP networks.

ADTS-CRC

ADTS-CRC includes CRC error correction and stream synchronization features to the ADTS transport and can be used for maintaining transmission integrity when the signal is degraded.

ADIF

Audio Data Interchange Format（ADIF）is a transport container more suited to files then streaming as the data stream is preceded with a header packet and then raw AAC data follows. ADIF may be used in applications where the audio will be muxed with other audio channels for multi-channel transport, but is not likely to be used in traditional streaming.

RAW

Raw mode will release the AAC data stream without any transport container at all and consists of nothing more than the encoded audio data.

Metadata


Telos
ProSTREAM
Metadata
Main
ProStream accepts metadata on port 9000 (both TCP and UDP). It parses the data using filters, small scripts using the Lua programming language (see http://www.lua.org for more information)
Select a metadata filter below then click the Save button. You can also click here to manage your metadata filters or upload new ones.
Select metadata filter:
XML-WideOrbit
Input code page (encoding):
UTF-8
Output code page (encoding):
UTF-8
Save

Metadata, or " data about the data ," can be combined with the audio stream for delivery to end clients. The metadata includes textual information about the current content of the audio stream, such as track title and artist, current program titles, or branding and can also include a URL to associate with the stream.

Most end clients which are used to play the streaming audio contain displays which can be used to present the text information in real-time. In the event that no metadata is provided to ProSTREAM, the stream's "Stream Name" configuration will be included as the stream's text content.

Data sent to the ProSTREAM is parsed internally by "filters", which are short scripts using the Lua programming language（see http://www.lua.org/）. Lua scripts can be modified and uploaded to ProSTREAM, to ingest incoming data and pass along the desired pieces（IE, "Track - Artist"）for real-time presentation within the playback client. ProSTREAM ships with a set of metadata filters and you may be able to feed it with data that matches one of the formats it understands. If your metadata source is not able to send data in one of the supported formats, let us know and we'll be able to help.

ProSTREAM is currently able to support incoming data formatted with the following code pages (http://en.wikipedia.org/wiki/Code_page):



- UTF-8 character encoding [default]

- ANSI - Windows
- 1250 – Central and East European Latin
- 1251 – Cyrillic
- 1252 – West European Latin
- 1253 – Greek
- 1254 – Turkish
- 1257 – Baltic
- 850 – "Multilingual（Latin-1）"（Western European languages）
- 932 - Japanese（DBCS）

Input

Automated playback systems typically provide for submitting metadata to a streaming server. Metadata connections are made to ProSTREAM via TCP, UDP connections to port 9000 or RS232 serial connections with an RS232 to USB adapter[2].

If no automated data stream is available, a manual entry form is included in ProSTREAM to allow manual entry of playlist information.

---

2 Connecting RS-232 serial data requires the use of a USB to RS-232 adapter manufactured by SYBA Multimedia. Fully tested and supported for use with the ProSTREAM (Order Telos part number 2091-00140).

Process

The most generic method of metadata parse is provided via the **Line Parser Sample** metadata filter.



As stated in the metadata table in the metadata webpage:

Line Parser Sample

This file implements a metadata filter that will parse strings that look like this: "t=title...|u=url...\n" where \n stands for a newline character.

If the playback system has mutable output to TCP, the output string may be able to be constructed for the ProSTREAM. If so, the key parameters would resemble the following:

Playlist Data Output

- IP address: **192.168.2.109** [IP of ProSTREAM]
- metadata port: **9000**
- string output: **t={title} - {artist} | u=http://mystation.org \n**

The automation system would then submit that string of characters via TCP to 192.168.2.109:9000 where the **Line Parser Sample.Lua** filter extrapolates the two variables from the input string and passes them to the encoder. The Line Parser Sample filter will also log both successes and failures in the Prostream system log.

> **Note:**
>
> **The Lua Line Parser requires that TCP strings be terminated with a line feed [\n] character. This is the indication the line filter uses to start processing the data. Character string parsers (often used with UDP data sources) do not share this requirement.**

SHOUTcast Stream Information



Icecast Stream Information

Connected VLC Media Player



Custom Metadata Filter Scripts

The scripting engine inside the ProSTREAM uses the Lua Programming Language. All data arriving via port 9000 (UDP & TCP), and RS232 will pass to the Lua script. Scripts are managed via the Metadata filters page at http://prostream.ip/filters.htm.

Lua Script Example

The following Lua script will engage the Lua Line Parser when written to a file and saved as a ProSTREAM metadata filter.

```
UseLineParser()
function OnLineReceived(text,endOfLine)
  local title=""
  local url="http://TelosAlliance.com"
  title=text
  LogInfo("LineParser Script: title='",title,"', url='",url,"'\n")
  SendMetaDataSong(title,url)   -- Send metadata to application
end
```

Save this script with a name, like LineParserRaw.Lua and use the filters page of the ProSTREAM to load the file to the ProSTREAM.

This script is an example of a basic script that takes any line of text submitted, and pass it directly though the metadata processor and reports the submitted characters to both the stream and the ProSTREAM system log when selected as the ProSTREAM's metadata filter.

Code Breakdown

`UseLineParser()`

This line configures the filter to process the incoming data one line at a time. Another available option is UseXmlParser(), which will configure the filter to process the incoming data as XML. If neither of these functions are called, the filter will default to processing the incoming data one character at a time.

`function OnLineReceived(text,endOfLine)`

This function is called to deal with the incoming data when the line parser is used. The line parser accumulates the incoming data until a new line, or line feed character is detected. If the incoming line is very long, the function may be called before an end of line character is detected. The **text** variable will contain the line data. The **endOfLine** variable will be true if the the function was called in response to an end of line character, or false otherwise.

`local title=""`

`local url="http://TelosAlliance.com"`

The **`local`** keyword introduces variables used by the script. The variable **`title`** is set to empty initially. The URL is set to the home URL for the stream. You may configure a different URL string here, if required by your player.

`LogInfo("LineParser Script: title='",title,"', url='",url,"'\n")`

The LogInfo function is used to write data to the ProSTREAM logs. This function, when used in combination with a syslog server application will allow real-time analysis of the script during the customization, or "debug" phase of the script creation.

```
[10:06:56.208] Core.Info: Url (URL encoded)=''
[10:06:56.208] Core.Info: Reply from ICEcast server at chico:8000 (lofi): HTTP/1.0 200 OK,
Metadata update successful
[10:08:38.937] Metadata.Info: Lua: SendMetaDataSong(text='Thievery Corporation - Sol
tapado', url='')
[10:08:38.937] Metadata.Info: MetaData SendMetaDataSong: No code page conversion needed
('UTF-8', 'UTF-8')
[10:08:38.951] Core.Info: meta_song(title='Thievery Corporation - Sol tapado',url='')
[10:08:38.952] Core.Info: Send metadata to SHOUTcast v2 server at 192.168.2.200...
[10:08:38.952] Core.Info: Title(XML encoded)='Thievery Corporation - Sol tapado'
```

All data inside the double quotes of the **LogInfo** container, **("LineParser Script: title='",title,"', url='",url,"'\n")** appears in the system log output. The variables from earlier in the script are specified by name to deliver their contents to the output. The **\n** specifies a newline character to represent the end of our submission to the log.

SendMetaDataSong(title,url)

The **SendMetaDataSong** function sends the title and url information to the stream server which will then pass it along to the clients. Although the word "Song" appears in the function name for historical reasons, you may send any information here; it does not have to be song related.

-- Send metadata to application

The Lua language uses two hyphens as a **comment** marker. The Lua interpreter will ignore any lines that begin with two hyphens. This provides a means to "mark up", or document, the source file with notes for future reference, but has no effect on the function of the script. In this case, the comment is a reminder of what the role is served by this line of code.

end

The end statement signifies the end to the commands which comprise the **OnLineReceived** function.

Metadata Tools

Metadata filter creation and tuning can be as nuanced as tuning an audio processor. In order to provide real-time control of the filter process, some helpful tools are available which may assist with the process.

Metadata Pack

http://omniaaudio.com/software/metatools/download

Metadata Pack contains two Windows EXE programs, **MetadataCapture.exe** and **MetadataSend.exe**.

The download also contains a PDF file explaining application use.

MetadataCapture.exe



Metadata Capture application allows the TCP or UDP data from a remote automation system to be routed to this application to capture a precise example of what data is being sent by the automation system to the ProSTREAM. When active, all data will be dumped to a file with timestamped delimiters.

Sample Output from Wide Orbit Automation for Radio

```
:::2012/10/27 23:25:08.641: Waiting for TCP connections on socket 9000:::

:::2012/10/27 23:25:14.581: Accept TCP connection on socket 9000 from
192.168.2.148:49296:::

<nowplaying><sched_time>7749700</sched_time><air_time>84336000</air_time><stack_
pos></stack_pos><title>Wah Wah Man</title><artist>Young-Holt Unlimited</
artist><trivia>What It Is! Funky Soul and Rare Gr</trivia><category>MUS</cate-
gory><cart>001U</cart><intro>0</intro><end></end><station>RockLAB</station><du-
ration>227100</duration><media_type>SONG</media_type><milliseconds_left></
milliseconds_left></nowplaying>

:::2012/10/27 23:25:23.292: Closed TCP connection on socket 9000 from
192.168.2.148:49296:::

:::2012/10/27 23:25:23.292: Exiting TCP thread on port 9000:::
```

MetadataSend.exe



The Metadata Send program allows for direct push of data to the ProSTREAM on command. Copying data from the Metadata Capture program and pasting into Metadata Send is a common way of testing the script.

Note:

To emulate TCP data, a linefeed is required. Data should be entered with at least one RETURN key press at the end of the line.

The download will also contain a PDF file explaining application use.

Syslog Server


SysLog Server
File
Options
About
Display
Emergency
Alert
Critical
Error
Warning
Notice
Info
Debug
Log messages (max 10000 lines)
192.168.2.109
Filter
Clear filter
Date
Source
Severity
Facility
Message
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: meta_song(title='e (1977 original Broadwa
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Send metadata to SHOUTcast v2 server at
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Title(XML encoded)='e (1977 original Broa
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Url (XML encoded)='http://TelosAlliance.
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: ShoutcastV2::UpdateMetadata CodePage1
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Send metadata to ICEcast server at 192.16
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Title(URL encoded)='e%20%281977%20o
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Url (URL encoded)='http%3a%2f%2fTelos
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Reply from ICEcast server at 192.168.2.20
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Send metadata to SHOUTcast v2 server at
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Title(XML encoded)='e (1977 original Broa
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Url (XML encoded)='http://TelosAlliance.
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: ShoutcastV2::UpdateMetadata CodePage1
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Send metadata to ICEcast server at chico:
5/7/2013 5:52:01 AM 192.168.2.109:51 Info Local0 Core.Info: Title(URL encoded)='e%20%281977%20o
Stop
Autoscroll
Select all
Copy selected to Clipboard
Clear
Server status: running on UDP port 514
Messages: Inf(9129), Cri(399), Err(472)

http://axiaaudio.com/open-source/software/axia-syslog-server/download

Syslog Server is a free syslog server application to display incoming system logs in real-time. If desired, logs can also be saved to file. Seeing the log at the exact moment of submitting a test batch of data can be extremely helpful and is recommended process for script creation.

The download will also contain a brief PDF file explaining application use.

File to TCP



http://omniaaudio.com/software/metatools/download

Some automation playback systems are only capable of writing metadata output to a file. The File to TCP application, when running, will watch for a file or folder to change, and when the change occurs, it copies the contents of the file to the TCP port of the ProSTREAM.

The download will also contain a PDF file explaining application use.

Command Line usage
Syntax

WatchFile2TCP.exe /run [configuration file]

Key

/run Start the instance when loaded (same as pressing the Start button manually)

Example

```
WatchFile2TCP.exe /run configuration_1.cfg
```

Streams

ProSTREAM can be configured to push connect to up to four separate streaming servers.

Set the target server to match the required streaming server protocol.



HTTP Streaming

ProSTREAM contains a built-in mini server on TCP port 8000. This server can accept only a few connections and should not be used as the main streaming server or be deployed to the public.

The HTTP server is intended to be used for stream monitoring with a player or to have another media server pull the stream from ProSTREAM allowing monitoring of the encoded stream. This is helpful in troubleshooting server connections or just as a quick way to test everything is working as expected. The HTTP server is also useful when adjusting audio processing parameters as the audio can be monitored with compression. The audio delay should also be shorter than listening to the stream delivered through an external server.

Test Stream Connection URL's

Codec 1	Codec 2
PLS: http://ip.address/play.pls	PLS: http://ip.address/play2.pls
M3U: http://ip.address/play.m3u	M3U: http://ip.address/play2.m3u
ASX: http://ip.address/play.asx	ASX: http://ip.address/play2.asx
RAW: http://ip.address:8000	RAW: http://ip.address:8010

Streaming Services

A streaming service can provide all that is needed for distribution of ProSTREAM's encoded audio stream. Typically pricing via a monthly base rate and bandwidth costs. The streaming service provider will provide the stream configurations for ProSTREAM and return to the client any number of services including stream link URL's to provide to listeners. A streaming service can also provide failover and optional configurations should a connection be lost.

Stream Server Service Providers

- TritonDigital: http://www.tritondigital.com/
- Akamai: http://www.akamai.com/
- LimeLight: http://www.limelight.com/
- Stream Guys: http://www.streamguys.com/

Additional streaming services can be found at http://www.radiotoolbox.com/hosts/

SHOUTcast



Target Server

Set the target server to SHOUTcast.

SHOUTcast Server Address

`IP.address:port` of the SHOUTcast server, I.E. 192.168.2.200:8010

SHOUTcast Server Password

Value of `password=` from the SHOUTcast configuration file.

Stream Name

When an Internet user or device connects to the stream, the Stream Name will be sent in the initial meta data burst. This title is typically displayed on the end-user's player or device. Capitalization and punctuation of Stream Name is fine and will be displayed as such in the end client.

Stream Genre

SHOUTcast DNAS server requires a genre field for all incoming connections. While the genre may not be displayed on the end user's device or client application, some streaming servers and services may publish the existence of the encoded audio stream in a directory. SHOUTcast recommends the genres listed in their forums: http://forums.winamp.com/showthread.php?t=303241

Stream URL

When an Internet user or device connects to the stream, the Stream URL will be sent in the initial meta data burst. This value can be set to an URL that is common to all the songs streamed to the SHOUTcast server (e.g. the website of the radio station).

Server version

ProStream can connect to SHOUTcast servers using SHOUTcast protocol version 1 or a newer enhanced SHOUTcast protocol version 2. If the server version is not known it will probably be the older protocol version 1.

Stream ID

If the SHOUTcast protocol version 2 is selected, a stream ID must be entered. Typically this will be 1 if only one stream is sent to the server.

Stream availability

Allows defining if the stream is meant to be public and can be included in a server specific directory listings or private and should not be listed to the end-users. A good example of this is SHOUTcast DNAS which will publish any streams configured as public to http://www.SHOUTcast.com/.

ICEcast



Target Server

Set the target server to ICEcast.

Audio Codec

Select which of the encoded streams will be delivered by this configuration.

ICEcast Server Address

IP.address:port of the ICEcast server, I.E. 192.168.2.200:8010

Mount Point

Specify a unique URL compatible string for the connection URL for the stream, I.E. hifi to have the connect string for this stream be http://192.168.2.200:8000/hifi. It is acceptable to specify an extension if desired, such as .mp3 or .aac.

Stream User Name
The default stream username for ICEcast is **source** unless it is overridden in the icecast.xml configuration file.

Stream Password
The stream password from the icecast.xml configuration file.

Metadata User Name
The ICEcast administrator username. Note that the configuration will work without a metadata username, but metadata will not pass to ICEcast or clients.

Metadata Password
The administrator password from the **icecast.xml** configuration file. Note that the configuration will work without a metadata username, but metadata will not pass to ICEcast.

Stream Name
The name of the stream as displayed to clients.

Stream Genre
Genre of the audio stream.

Stream URL
Web address of the station's website.

Stream availability
Allows defining if the stream is meant to be public and can be included in a server specific directory listings or private and should not be listed to the end-users.

RTP



Target Server

Set the target server to RTP

Audio Codec

Specify which of the two codec encodes to use for the RTP stream.



Note:

RTP allows uncompressed delivery as well. Select a PCM codec to be able to specify the Samples per RTP packet.

RTP destination address

Enter the destination UDP address to which RTP packets will be sent. Address can be unicast or multicast.

RTP destination port

Enter the UDP port to which RTP packets will be sent.

Time to live (TTL)

Defines how "far" from a sending host a given UDP packet should be forwarded. For example, use value 1 to limit UDP streams to local network subnet only.

Stream name

The name entered here will be sent in the SDP discovery broadcast messages. This title is typically displayed on the end-user's player or device when stream is discovered and played.

RTP interface

If more than one network interface for ProStream is configured, RTP interface selection allows to define to which network interface RTP stream will be sent. Usually interface needs to be set to LAN to broadcast stream to Local Area Network.

RTMP



Target server

Set the target server to RTMP for RTMP streaming services. Service providers like TritonDigital, Akamai, and LimeLight often use RTMP services for live audio streaming.

Server address

Enter the server address and port number where the address and port are separated by a colon character. For example, if the address is 192.168.1.23 and the port is 1935, you would enter 192.168.1.23:1935 in the address field.

Use Authentication

If RTMP server needs authentication, set this field to "yes." The fields for **stream username** and **stream password** will appear automatically.



Stream user name
If RTMP authentication is selected, enter the server username.

Stream password
If RTMP authentication is selected, enter the server password.

Publish path
Enter the stream publish path. Usually this will be the RTMP application name used to receive the stream (e.g. "live" is the default RTMP application for Adobe Flash Media Server).

Stream name
Enter the RTMP stream name. RTMP stream can also be written with multiple paths (e.g. path1/path2/livestream).

Note:

RTMP streams require 44100 Hz sample rate to be used in the ProStream MP3/AAC codec settings and RAW or ADIF transport format when AAC codec is selected.

System


Telos
ProSTREAM
System
Main
Select the desired system options below.
Software Bank #1: v1.5beta, Build 2012-03-29, Inactive
Run this version
Click the Update Software button to view a list of public software releases or to load an update file from your PC.
Update software
Software Bank #2: v2.0.22beta, Build 2013-04-18, Running...
Reboot
Run the software from the other bank to update the software in this bank.
ProStream v2.0.22beta - Build 2013-04-18 - Copyright © 2013 TLS Corporation

The system page can be accessed to either switch the firmware bank of the ProSTREAM, or to reboot the unit. The System Web interface will also allow the upload of new software images.

Note:

It is good practice to schedule periodic maintenance of the ProSTREAM encoder and check for updated software. New software can be found at http://telos-systems.com/prostream/.

Firmware is delivered via a single compressed .tgz file. From the system page of the web interface, the "Update Software" button will bring up a file browser where the new firmware image file can be updated to the software bank. Once uploaded, ProSTREAM can be rebooted to the new software bank. All existing configuration options will remain intact.

Advanced Options

Logs/Date Time



Date/Time

If required, it is possible to reset the ProSTREAM system time from the Logs menu.

Logs

To help troubleshooting problems, ProStream allows to view last 500 system log messages when the web interface control panel is used. If a problem occurs（cannot connect to the streaming server, etc.）, log messages should be reviewed before any ProStream reboots because the log messages are deleted when the unit reboots.

If more than 500 log message lines must be reviewed it is possible to set up a SysLog compatible server on another computer and forward log messages to this server by entering its IP address in the ProStream logs section. This allows all new log messages to be sent to the remote SysLog server to assist with system setup and diagnosis.

Syslog Server

Assign the IP address of a computer running a syslog server. All logs written to the ProSTREAM syslogs will also be written at the same time to the syslog server assigned.

A syslog server will present logs as they are generated which can assist with setup and diagnosis. Metadata setup especially benefits from use of the real-time syslog server.

Ping Service



The ping service provides a means to test connectivity to certain IP addresses from the ProSTREAM. This can be useful in diagnosing connection issues from the ProSTREAM to remote servers. Ping results will display both in the Web interface and in syslog as *pinger* events.

```
pinger.Warning: Host 192.168.1.200 failed to respond to pings after 15 sec!
```

Host IP

Specify up to four (4) separate IP addresses to test for ping response.

Ping Interval

Specify the interval in seconds to wait between ping attempts.

Alarm after

Trigger an alarm after a specified number of seconds of failed attempts. Must be equal to or larger than the Ping interval.

The ping service is not configurable via the front panel.

Configure Static Routes

Static Routing allows path selection for specific connections. A static route allows explicit specification of the gateway and the network port（WAN or LAN）.



Destination Address

Destination address can be expressed as an IP address or a network range in CIDR notation [cidr/flsm supernet calculator]. IE 192.168.0.0/24 expresses the same information as 192.168.2.0 : 255.255.255.0 in network speak.

Note:

If a single IP address is entered, ProSTREAM will append the IP address with /32 to indicate a single IP address in the range.

Gateway Address

A gateway is an IP address of a router, or a device which can speak to multiple networks.

Interface

Interface specifies which physical network connection the ProSTREAM should use for this communication. LAN and WAN refer to the two back-panel network ports.

Note:

The Gateway Address must be within the range specified for the selected port (as per the ProSTREAM's Network configuration) or the route will not be accepted.

View network diagnostics

Network diagnostics will present the standard Linux output of network configurations. No user functions are included.

Interface configuration

```
-- Interface configuration
eth0      Link encap:Ethernet  HWaddr 00:13:95:06:eb:e2
          inet addr:192.168.2.109  Bcast:192.168.2.255  Mask:255.255.255.0
          inet6 addr: fe80::213:95ff:fe06:ebe2/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:5225450 errors:0 dropped:0 overruns:0 frame:0
          TX packets:418301 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:646595854 (616.6 MiB)  TX bytes:430907987 (410.9 MiB)
          Interrupt:40 Base address:0xe000

lo        Link encap:Local Loopback
          inet addr:127.0.0.1  Mask:255.0.0.0
          inet6 addr: ::1/128 Scope:Host
          UP LOOPBACK RUNNING  MTU:16436  Metric:1
          RX packets:2825 errors:0 dropped:0 overruns:0 frame:0
          TX packets:2825 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
          RX bytes:348397 (340.2 KiB)  TX bytes:348397 (340.2 KiB)
```

Link information

```
-- Link information
1: lo:  mtu 16436 qdisc noqueue state UNKNOWN
    link/loopback 00:00:00:00:00:00 brd 00:00:00:00:00:00
2: dummy0:  mtu 1500 qdisc noop state DOWN
    link/ether 62:ea:d4:7e:98:68 brd ff:ff:ff:ff:ff:ff
3: eth0:  mtu 1500 qdisc pfifo_fast state UNKNOWN qlen 1000
    link/ether 00:13:95:06:eb:e2 brd ff:ff:ff:ff:ff:ff
4: sit0:  mtu 1480 qdisc noop state DOWN
    link/sit 0.0.0.0 brd 0.0.0.0
5: usb0:  mtu 1492 qdisc noop state DOWN qlen 1000
    link/ether ba:4e:73:4f:5c:c1 brd ff:ff:ff:ff:ff:ff
```

IP rules

```
-- IP rule
0:      from all lookup local
32764:  from all to 192.168.2.109 lookup eth_tbl
32765:  from 192.168.2.109 lookup eth_tbl
32766:  from all lookup main
32767:  from all lookup default
```

IP routing

```
-- IP routing
192.168.2.0/24 dev eth0  proto kernel  scope link  src 192.168.2.109
default via 192.168.2.3 dev eth0

Kernel IP routing table
Destination     Gateway         Genmask         Flags Metric Ref    Use Iface
192.168.2.0     *               255.255.255.0   U     0      0        0 eth0
default         192.168.2.3     0.0.0.0         UG    0      0        0 eth0

Kernel IP routing cache
Source          Destination     Gateway         Flags Metric Ref    Use Iface
192.168.2.50    239.192.255.3   239.192.255.3   ml    0      0       87 lo
192.168.2.109   239.192.255.3   239.192.255.3   ml    0      0      237 eth0
192.168.2.202   192.168.2.109   192.168.2.109   il    0      0     1865 lo
192.168.2.201   192.168.2.109   192.168.2.109   il    0      0      501 lo
192.168.2.90    239.192.255.3   239.192.255.3   ml    0      0      245 lo
192.168.2.209   192.168.2.255   192.168.2.255   ibl   0      0       25 lo
192.168.2.20    239.192.255.3   239.192.255.3   ml    0      0       69 lo
192.168.2.204   192.168.2.255   192.168.2.255   ibl   0      0       33 lo
google-public-d 192.168.2.109   192.168.2.109   l     0      0      134 lo
192.168.2.109   192.168.2.200   192.168.2.200         0      3        6 eth0
192.168.2.204   192.168.2.109   192.168.2.109   il    0      0      237 lo
192.168.2.109   239.192.255.3   239.192.255.3   ml    0      0       41 eth0
192.168.2.202   255.255.255.255 255.255.255.255 ibl   0      0       60 lo
```

View memory usage diagnostics

```
       Mem: 120196K used, 901412K free, 0K shrd, 1216K buff, 22096K cached
CPU: 16.6% usr  8.3% sys  8.3% nic 66.6% idle  0.0% io  0.0% irq  0.0% sirq
Load average: 0.24 0.24 0.26 1/93 2026
  PID  PPID USER     STAT   VSZ %MEM CPU %CPU COMMAND
 1912  1910 root     S    82592  8.0   0 24.9 ./core
 2026  1923 root     R N   2604  0.2   0  8.3 top -b -n1
 1923     1 root     S N  58668  5.7   0  0.0 ./webcfg
 1925     1 root     S N  53824  5.2   0  0.0 ./metadata
 1790     1 root     S    28536  2.7   0  0.0 /usr/sbin/rsyslogd -c3
 1924     1 root     S N  27972  2.7   0  0.0 ./plcysrv
 1922     1 root     S N  23044  2.2   0  0.0 ./ui
 1926     1 root     S N  19648  1.9   0  0.0 ./pinger
 1908  1906 root     S N  11424  1.1   0  0.0 ./syslog
 1802     1 root     S     5372  0.5   0  0.0 /usr/sbin/sshd
 1910     1 root     S     5332  0.5   0  0.0 ./core
 1815     1 root     S     5240  0.5   0  0.0 /usr/sbin/snmpserv /etc/snmpserv/s
 1878     1 root     S     3300  0.3   0  0.0 /usr/sbin/axialwrd
 1906     1 root     S N   3228  0.3   0  0.0 ./syslog
 1882     1 root     S     3020  0.2   0  0.0 /usr/sbin/axiaadvd -fspy /tmp/lwst
 1886     1 root     S     2976  0.2   0  0.0 /usr/sbin/axiagpr
  101     1 root     S <   2884  0.2   0  0.0 udevd --daemon
 1830     1 root     S     2604  0.2   0  0.0 /usr/sbin/crond
    1     0 root     S     2148  0.2   0  0.0 init [2]
 1811     1 root     S     2000  0.2   0  0.0 /usr/sbin/inetd
 2025  1923 root     S N   1996  0.1   0  0.0 route -C
 1966     1 root     S     1812  0.1   0  0.0 /sbin/getty 38400 tty1
 1967     1 root     S     1812  0.1   0  0.0 /sbin/getty 38400 tty2
 1968     1 root     S     1812  0.1   0  0.0 /sbin/getty 38400 tty3
 1969     1 root     S     1812  0.1   0  0.0 /sbin/getty 38400 tty4
 1970     1 root     S     1812  0.1   0  0.0 /sbin/getty 38400 tty5
 1971     1 root     S     1812  0.1   0  0.0 /sbin/getty 38400 tty6
 1891     1 root     S     1668  0.1   0  0.0 ./onnetchg /flash/ipcodec/current/
```

The memory usage page is based on the standard Linux tool **top**. This presents a list of all processes in the CPU and can be very helpful in debugging rogue processes. No user functions are included.

View system diagnostics

```
       : BAR 7: assigned [io  0x1000-0x1fff]
[    0.245098] pci 0000:00:1c.0: PCI bridge to [bus 01-01]
[    0.245108] pci 0000:00:1c.0:   bridge window [io  0x1000-0x1fff]
[    0.245123] pci 0000:00:1c.0:   bridge window [mem 0x80000000-0x801fffff]
[    0.245135] pci 0000:00:1c.0:   bridge window [mem 0x80200000-0x803fffff pref]
[    0.245150] pci 0000:00:1c.1: PCI bridge to [bus 02-02]
[    0.245159] pci 0000:00:1c.1:   bridge window [io  0xe000-0xefff]
[    0.245172] pci 0000:00:1c.1:   bridge window [mem 0xfeb00000-0xfebfffff]
[    0.245184] pci 0000:00:1c.1:   bridge window [mem 0xcff00000-0xcfffffff pref]
[    0.245214] pci 0000:00:1c.0: enabling device (0104 -> 0107)
[    0.245238] pci 0000:00:1c.0: PCI INT A -> GSI 16 (level, low) -> IRQ 16
[    0.245252] pci 0000:00:1c.0: setting latency timer to 64
[    0.245275] pci 0000:00:1c.1: PCI INT B -> GSI 17 (level, low) -> IRQ 17
[    0.245287] pci 0000:00:1c.1: setting latency timer to 64
[    0.245299] pci_bus 0000:00: resource 4 [io  0x0000-0x0cf7]
[    0.245307] pci_bus 0000:00: resource 5 [io  0x0d00-0xffff]
[    0.245316] pci_bus 0000:00: resource 6 [mem 0x000a0000-0x000bffff]
[    0.245325] pci_bus 0000:00: resource 7 [mem 0x000d0000-0x000dffff]
[    0.245335] pci_bus 0000:00: resource 8 [mem 0x3fc00000-0xdfffffff]
[    0.245344] pci_bus 0000:00: resource 9 [mem 0xf0000000-0xffffffff]
[    0.245353] pci_bus 0000:01: resource 0 [io  0x1000-0x1fff]
[    0.245362] pci_bus 0000:01: resource 1 [mem 0x80000000-0x801fffff]
[    0.245371] pci_bus 0000:01: resource 2 [mem 0x80200000-0x803fffff pref]
[    0.245380] pci_bus 0000:02: resource 0 [io  0xe000-0xefff]
[    0.245389] pci_bus 0000:02: resource 1 [mem 0xfeb00000-0xfebfffff]
[    0.245398] pci_bus 0000:02: resource 2 [mem 0xcff00000-0xcfffffff pref]
[    0.245531] NET: Registered protocol family 2
[    0.245701] IP route cache hash table entries: 32768 (order: 5, 131072 bytes)
[    0.248051] size: 524280
[    0.248135] TCP established hash table entries: 131072 (order: 8, 1048576 bytes)
[    0.249463] TCP bind hash table entries: 65536 (order: 6, 262144 bytes)
[    0.249868] TCP: Hash tables configured (established 131072 bind 65536)
[    0.249876] TCP reno registered
[    0.249886] UDP hash table entries: 512 (order: 1, 8192 bytes)
[    0.249908] UDP-Lite hash table entries: 512 (order: 1, 8192 bytes)
```

System diagnostics presents the output of the Linux **dmesg**. This can be helpful in diagnosing startup or other system-level issues. No user functions are included.

View front panel image

Refresh page to capture current front panel image. Right-click the image link below to save it to your PC.

Screen Image Link

View front panel image will present the same image as what is currently displayed on the unit front panel. A direct link is included on this page. No user functions are included.

Display public IP (works only if DNS is configured)

Display public IP will return a simple HTML page with nothing more than the public IP address of the routed IP network. Since this tools refrerences against http://whatismyip.akamai.com/, failure of this command can be an indicator of an improperly or un-configured DNS entry under the ProSTREAM's Network Settings. If in doubt, Google's public DNS servers can be used @ 8.8.8.8 and 8.8.4.4.

```
<!DOCTYPE HTML PUBLIC "-//W3C//DTD XHTML 1.0 Transitional//EN" "http://www.w3.org/TR/xhtml1/DTD/xhtml1-transitional.dtd">
<html xmlns="http://www.w3.org/1999/xhtml" xml:lang="en" lang="en">
<head>
  <meta http-equiv="Content-Type" content="text/html; charset=utf-8" />
  <title>Public IP</title>
</head>
<body>
        71.87.60.35
</body>
</html>
```

5 Omnia Processing

The dynamics processing algorithms in use in the ProSTREAM are based upon Omnia Audio's highly successful Omnia.3net, a hardware-based DSP audio processor.

ProSTREAM employs the following Omnia processing architecture:

- Input
- Wideband AGC
- 3 Band Combined Compressor/Limiter
- Adjustable Bandwidth Low-pass Filter
- Final Look-Ahead Limiter
- Output
- Processing Preset Editor/Preset Management

All audio processing adjustments are performed in the Preset Editor, which is only available via the web interface. A "preset" represents all of the control values for each control in the Omnia processor. When a preset is chosen for the processor, control values for the processor's settings are loaded into the processing structure and applied to the input audio.

Presets allow different processing setups to be loaded into the processor. Factory presets have been provided as starting points for customizing your sound.

It is possible to gain dramatic sonic improvement from ProSTREAM's Omnia processing right away using one of the factory presets. Start by selecting one from the "Omnia Processing" menu and then click "...edit" to bring up the Preset Editor.



Preset Editor

Using the Preset Editor, it is possible to customize the chosen preset to suit your own aural requirements.

Note:

Be sure to click "Save" in the upper-right hand corner of the editor window when you are finished to save your changes. If you do not, they will be lost when you exit the editor.



Processor Adjustment Overview

1. Start with a factory preset and adjust processor values in small increments.
2. Listen to the post-processed audio, ideally through the codec to be used, then adjust, and listen again. Aural evaluation should occur over time, not in short moments.
3. While making changes to the system, adjust in small increments. Do not make too many different adjustments all at once. Multiple adjustments at once can make for more difficult determination of what affected an aural change. Make changes in increments of no more than +0.5 dB or -1 dB, or in 1 or 2 step increments. Turn functions on and off to better determine their effect on the audio.
4. Sleep on it. Spend time adjusting and then listening, and when the system gets to a point where it sounds good, stop. When making changes to processing, ears become less sensitive to the adjustments. Spreading the adjustment period over a number of days is recommended.

The following section will detail each control if you'd like to customize one of the factory presets to get your own custom sound.

If you are using a factory preset as-is, please read the "Input" and "Output" adjustment sections as these are very important for proper operation and sound quality.

Processor Adjustment

Bypass

The Bypass control (which appears in each menu), when turned ON, will completely bypass all processing, effectively connecting the input directly to the output.

Input



Proper input gain is essential for optimum processing.

Gain

Set the "Gain Left" and "Gain Right" controls so that the peak-reading Input meters are peaking "just into the red" at -12 dBFS with normal "0VU" program audio playing.

WB AGC



The Wide-Band AGC performs overall gain-riding to the input signal over a 30dB range. It acts like an automated "hand on the pot", keeping the overall level to the 3-Band compressor/limiter nice and consistent.

Drive

Once the Input Gain is set, you can adjust the Wide-Band AGC Drive if desired. This is measured using the "WB" gain-reduction meter. This meter reads from the top down where "0" is no gain-reduction at all. Normally, this should read down to between about 10-15dB with normal "0VU" program audio playing. this will allow room both above and below for automatic gain adjustment.

Gate

This is a silence gate that freezes the gain when silence is detected to help keep noise from being brought up during program pauses. The normal setting is "On" but the silence gate can be defeated by setting this control to "Off" if desired.

Release

This controls the overall speed of operation of the WB AGC. "Slow" will preserve more of the natural dynamic range in the program material.. "Fast" will bring up lower level passages faster and react faster to program level changes. "Medium" is a nice compromise between the two.

Bass



Some bass boost is normally used when processing to balance out the spectrum and add some "punch." These two controls adjust the amount of the ProSTREAM's bass enhancement section. They are more than just simple EQ's. If your source material has it, ProSTREAM will put it in the mix, and with muscle!

Making changes to the bass is done using the following parameters, and for maximum effectiveness, in the order listed: (NOTE: Settings of "0.0" apply no bass boost.)

1. In the Bass menu, increase the amount of Deep Bass boost to taste. This is the lowest "kick drum" bass. so be sure to monitor with speakers or headphones that can reproduce bass below 80Hz.
2. In the Bass menu, increase the amount of Phat Bass boost to taste. This special bass effect can help smaller speakers sound like they have more bass than they really do.
3. Increase the drive to the LF AGC in the LO AGC screen.
4. Speed up the release times of the LO AGC section.
5. Slightly increase the low control in the mixer section.

When processing, moderation is the key. If all of the above steps are utilized in the pursuit of more bass, severe low frequency over-enhancement can occur. Excessive bass boost can produce the illusion that the presence and high frequencies have been lost. They are still there, but are being acoustically masked by the lower frequencies. Generally, an increase in the Bass menu's bass boost functions alone will provide more than sufficient enhancement to the low end.

Phat Bass

Phat bass widens the higher low-end frequencies in an effort to expand bass sound on smaller playback speakers.

Deep Bass

Deep bass focuses on frequencies of 80hz and below.

X-Over



The X-Over (crossover) splits the audio from the WB AGC into 3 frequency bands so each band can be optimally processed. The three bands are: Lo (bass) Mid (midrange - voice and solo instruments) and Hi (treble). There are no adjustable controls in the crossover section.

Low,Mid,Hi AGC



Each band has a Drive, Gate and Release control, similar the the WB AGC.

Drive

The Drive control adjusts the volume of the audio from the crossover into the compressor/limiter for the selected band. Higher settings will drive the selected band into more gain-reduction. Some EQ can also be done with the Drive controls if one band is adjusted differently than the others. Start by setting them equally though.

More drive will provide a denser, more compressed (but louder) sound. Less drive will provide a more natural and "open" sound.

Generally, you will see these meters move faster than the WB AGC. Generally, between 5 and 10 dB of gain-reduction is a good nominal amount. Note that the Hi band may show less gain-reduction than the others. This is normal.

Gate

This is a silence gate that freezes the gain when silence is detected to help keep noise from being brought up during program pauses. The normal setting is "On" but the silence gate can be defeated by setting this control to "Off" if desired.

Release

This controls the overall speed of operation of the compressor/limiters. "Slow" will preserve more of the natural dynamic range in the program material.. "Fast" will react faster to program level changes. "Medium" is a nice compromise between the two.

Mix



The final mixer level controls set the output level of each of the 3 compressor/limiter bands into the final look-ahead limiter. Note that it is possible to reduce the level below "0" as well as increase it.

Level [Low, Middle, High]

While some EQ'ing can be done at this stage, be careful not to turn one band's mix level up too much higher than the others. This will cause too much of that band's signal to hit the final limiter, causing possible undesired effects such as overload (excessive limiting of one band's audio) or pumping.

It is generally better to leave these set at their default settings and use the Bass and Drive controls to EQ the sound to your liking.

Then, if further correction is required, you can reduce the level of a particular band here if needed, such as reducing the High mixer if the audio sounds too bright.

Try to use the mixer only to reduce rather than boost as a rule-of-thumb.

Final Limiter



The final limiter is a fast, look-ahead peak limiter that provides final peak control to the processed audio.

Limiter

Generally, set the Limiter level control until you see about 2 to 4dB of gain-reduction on the Final Limit meters with normal program audio playing.

Too low of a setting will decrease loudness while too high of a setting can sound too dense and over-processed.

Output



Gain [Left & Right]

The Gain Left and Gain Right controls set the final peak output level that feeds the codec. Normally, this can be set to just under the maximum setting of 6.0dB. This setting corresponds to about 0dBFS. Normally, a setting of 5.8dB should be fine, but be sure to listen for clipping distortion through the codec and adjust as needed.

Output Filter

Dynamics processing is an extremely useful tool for reducing audible artifacts from lossy-compression codecs. High frequencies tend to be the first perceptible annoyances, followed by that swishy-swirly water like sound common at lower bitrates. These artifacts can be reduced, and in some cases eliminated, when audio processing is applied as a tool.

Generally, as codec bitrates are reduced, so is the audio bandwidth. ProSTREAM contains a selectable low pass filter in the output section. Reducing the audio bandwidth by using a lower frequency setting can help reduce the audible side-effects of low bitrate coding. Additionally, reducing the High band MIX setting can help.

Also, operating the HF Band in the slow release time will reduce HF density which improves intelligibility as the encoder masking algorithm is not loaded as heavily with HF content.

Managing Presets

From the Omnia Processing menu, click Manage Presets to open the preset management window.

In the example on the next page, we made some changes to the PhatOne preset and then clicked “Save”.

Now, here in the Manage Presets window you will see that the PhatOne preset line has an additional choice: “Restore”. If we were to click on “Restore” now, before saving a copy, the original factory PhatOne preset will be restored and the changes we made would be lost.

So if you do make some changes to a preset and save them, it would be a good idea to click “Copy” to save the preset with your changes to a new name. This will create a user preset with that name.

Once that is done, you can Restore the factory preset and can compare it to the new user preset that contains the changes you made from the original.

Note that the Restore option will only appear when you save custom changes to a factory preset or delete a factory preset. This means that factory presets can always be restored, even if you delete them to remove them from the preset list. This IS NOT the case for user presets. Deleting a user preset is final.


Telos
ProSTREAM
Omnia Processing
Omnia Processing
Main
This page allows you to manage your Omnia presets. Right-click on the preset name and select "Save As..." to save a backup copy on your PC, or use the provided links to copy, rename, or delete a preset. You can also upload new presets below.
Please do not use your browser's back or page refresh buttons on this page. Doing so may repeat the last operation with unintended consequences.
Available Omnia Presets:
Music 24kbps Copy | Rename | Delete
Music 32kbps Copy | Rename | Delete
Normalize Copy | Rename | Delete
PhatOne Copy | Rename | Delete | Restore
Smooth Copy | Rename | Delete
Sparkle Copy | Rename | Delete
Squashed! Copy | Rename | Delete
Talk Copy | Rename | Delete
Talk 24kbps Copy | Rename | Delete
Talk 32kbps Copy | Rename | Delete
Upload new preset:
Browse...
Apply update

6 Warranty and Application Cautions

ProSTREAM LIMITED WARRANTY

This Warranty covers "the Products," which are defined as the various audio equipment, parts, software and accessories manufactured, sold and/or distributed by TLS Corp., d/b/a Telos Systems (hereinafter "Telos Systems").

With the exception of software-only items, the Products are warranted to be free from defects in material and workmanship for a period of two years from the date of receipt by the end-user. Software-only items are warranted to be free from defects in material and workmanship for a period of 90 days from the date of receipt by the end-user.

This warranty is void if the Product is subject to Acts of God, including (without limitation) lightning; improper installation or misuse, including (without limitation) the failure to use telephone and power line surge protection devices; accident; neglect or damage.

EXCEPT FOR THE ABOVE-STATED WARRANTY, TELOS SYSTEMS MAKES NO WARRANTIES, EXPRESS OR IMPLIED (INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE).

In no event will Telos Systems, its employees, agents or authorized dealers be liable for incidental or consequential damages, or for loss, damage, or expense directly or indirectly arising from the use of any Product or the inability to use any Product either separately or in combination with other equipment or materials, or from any other cause.

In order to invoke this Warranty, notice of a warranty claim must be received by Telos Systems within the above-stated warranty period and warranty coverage must be authorized by Telos Systems. If Telos Systems authorizes the performance of warranty service, the defective Product must be delivered, shipping prepaid, to: Telos Systems, 1241 Superior Avenue East, Cleveland, Ohio 44114.

Telos Systems at its option will either repair or replace the Product and such action shall be the full extent of Telos Systems' obligation under this Warranty. After the Product is repaired or replaced, Telos Systems will return it to the party that sent the Product and Telos Systems will pay for the cost of shipping.

Telos Systems' authorized dealers are not authorized to assume for Telos Systems any additional obligations or liabilities in connection with the dealers' sale of the Products.

7 Specifications

Line Input	**+4dBu input**
THD+N Pro/Pro	**< 0.03% @ +12dBu, 1 kHz Sine;**
Freq Response	**+/- 1dB 25– 20 kHz**
Head Room	**18dB**
Dynamic Range	**> 87dB Unweighted** **> 90 dB "A" Weighted**
Crosstalk	**Over 80 db**
Output Clipping	**+ 22dBu**
Output Impedance	**50 Ohm differential**
Input Impedance	**6K Ohm differential**
Analog to Digital Converter	**24bits**
Digital to Analog Converter	**24bits**
Power	**115Vac 14.2 Watts**

ProSTREAM Self Test

1. Press and hold the Headphone Volume Knob in during power up until the screen activates.
2. Release Headphone Volume Knob and then press the Control Knob.
3. Activate all front panel controls to test function.
4. Once complete, the "Frontpanel" status will confirm OK to indicate controls are good.

8 Safety Notification

This symbol, wherever it appears, alerts you to the presence of uninsulated, dangerous voltage inside the enclosure – voltage which may be sufficient to constitute a risk of shock.

This symbol, wherever it appears, alerts you to important operating and maintenance instructions. Read the manual.

1. Read All Instructions. All safety and instructions must be read before operating the product.
2. Retain All Instructions. All safety and operating instructions must be maintained for future reference.
3. Heed All Warnings. All warnings on the product and those listed in the operating instructions must be adhered to.
4. Follow All Instructions. All operating and product usage instructions must be followed.
5. Heat. This product must be situated away from any heat sources such as radiators, heat registers, stoves, or other products（including power amplifiers）that produce heat.
6. Water and Moisture. Do not use this product near water.
7. Attachments. Do not use any attachments not recommended by the product manufacturer as they may cause hazards.
8. Power Sources. This product must be operated from the type of power source indicated on the marking label and the installation instructions. If you are not sure of the type of power supplied to your facility, consult your local power company.
9. Grounding and Polarization. This product is equipped with a polarized AC plug with integral safety ground pin. Do not defeat the safety ground in any manner.
10. Power Cord Protection. Power supply cords must be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to the cords at AC wall plugs and convenience receptacles, and at the point where the cord plugs into the product.
11. Lightning. For added protection during a lightning storm, or when the unit is left unattended or unused for long periods of time, unplug the unit from the AC wall outlet. This will prevent damage to the product due to lightning and power surges.
12. Overloading. Do not overload AC wall outlets, extension cords, or integral convenience outlets as this can result in a fire or electric shock hazard.
13. Object and Liquid Entry. Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
14. Accessories. Do not place this product on an unstable cart, stand, tripod, bracket or table. Any mounting of the product needs to follow the manufacturer's instructions.

15. Servicing. Refer all servicing to qualified service personnel.

16. Damage Requiring Service. Unplug this product from the wall AC outlet and refer servicing to qualified service personnel under the following conditions:

    - ♦ When the AC cord or plug is damaged.
    - ♦ If liquid has been spilled or objects have fallen into the product.
    - ♦ If the product does not operate normally（following operating instructions）.
    - ♦ If the product has been exposed to rain or water.
    - ♦ If the product has been dropped or damaged in any way.
    - ♦ When the product exhibits a distinct change in performance （outside of normally operating specifications）.

17. Replacement Parts. When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer. Unauthorized substitutions may result in fire, electric shock, or other hazards.

18. Safety Check. Upon completing of any repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

19. Cleaning. Do not use liquid cleaners or aerosol cleaners. Use only a damp cloth for cleaning the exterior of the product only.